

How to install BOW (Kit A) to an F1 DataStorm system.



First remove the Stow Bracket's 3 screws on each side. Of the plastic cover.

Now remove the five screws holding the plastic cover on. There is one on the right side and four on the left side of the cover.



Now carefully remove the plastic cover. If you have the blue LED hooked to the plastic cover be careful not to pull on these wires or let the plastic cover hang from them..

For the KIT A we have two brown coax cables run down inside the arm of the unit. Carefully pull these coax out of the arm.



Now take an Allen Wrench kit and take the two screws off the top of the grey bracket. And remove the grey bracket.

Also remove the clear plastic retainer under the grey arm. This may get a little jammed but pull in a steady motion and it will come out. Then discard this retainer.



Now take the KIT A and place it into the groove. Fitting it snug into position.

There are three screw holes on the kit that must be screwed in.



Now connect the two coax cables that we pulled out of the arm.

Now place the grey bracket back over the Kit A and use the Allen Wrench to put the screws back in.



Now replace the plastic cover and screw in the five retaining screws. Be careful not to bind any wires when closing the plastic cover.