


# DW4020: 1 Static IP NO ROUTER



## NO ROUTER [1 Computer]



### D2 Settings:

- IP**-192.168.0.2
- Subnet**-Leave as is
- Modem Gateway**-Leave as is
- \*Router Gateway**-Leave as is
- DNS**-Leave as is

\*Only available on v.3.5.4 and higher

### Computer(s) Settings [Example Static IP\*\* used]:

- |                                |                              |
|--------------------------------|------------------------------|
| <b>1st IP</b> -66.88.44.33     | <b>2nd IP</b> -192.168.0.10  |
| <b>Subnet</b> -255.255.255.252 | <b>Subnet</b> -255.255.255.0 |
| <b>Gateway</b> -66.88.44.32    | <b>Gateway</b> -NONE         |
| <b>DNS</b> -66.82.4.8          |                              |
| 66.82.4.12                     |                              |

\*\*The static IP is given at the time of commissioning. Refer to your commissioning documentation for actual IP settings.

**MUST PROGRAM THE SATELLITE SPECIFIC SETTINGS [See the D2 Configuration section of the setup manual]**

## **DW4020, D2, and Computer IP Guide [1 Static IP] NO Router**

- **DW4020 Settings [1 Static IP]**

**WAN**

IP-i.e. 66.88.44.32 [See your SAN confirmation sheet for actual IP's]  
SUBNET-255.255.255.252

**LAN**

IP-192.168.0.1  
SUBNET-255.255.255.252

- **D2 Settings**

**IP Configuration**

IP-192.168.0.2  
Subnet-Leave as is  
Modem Gateway- Leave as is  
\*Router Gateway-Leave as is  
DNS-Leave as is  
\*DataStorm Beta v.3.5.4 or higher

- **Your Computer's Settings**

**1<sup>st</sup> IP Configuration [for Internet access and DW4020 access]**

IP-i.e. 66.88.44.33 [One IP Above the DW4020 Address; See your SAN  
confirmation sheet for actual IP's]  
SUBNET-255.255.255.252  
GATEWAY-i.e. 66.88.44.32 [the WAN IP of the DW4020]  
DNS-1-66.82.4.8  
2-66.82.4.12

**2<sup>nd</sup> [Advanced] IP Configuration [for D2 access]**

IP-192.168.0.10  
SUBNET-255.255.255.0

**PLEASE REFER TO YOUR INSTALLER OR SAN CONFIRMATION SHEET FOR  
ACTUAL IP SETTINGS ON YOUR MODEM DEVICE**