


DW4020: NAT Enabled



- Control Cable —
- Receive Cable —
- Transmit Cable —
- Ethernet Cable —
- Power Connection - - -

D2 Settings:

- IP**-Leave as is
- Subnet**-Leave as is
- Modem Gateway**-Leave as is
- *Router Gateway**-Leave as is
- DNS**-Leave as is

*Only available on v. 3.5.4 and higher

MUST PROGRAM THE SATELLITE SPECIFIC SETTINGS [See the D2 Configuration section of the setup manual]

Computer(s) Settings:

- Obtain IP Address Automatically**
- Obtain DNS Server Automatically**

DW4020, D2, and Computer IP Guide [NAT Enabled]

Optional Requirements: Wireless Access Point

- **DW4020 Settings [NAT Enabled]**

IP Configuration

IP-192.168.0.1

SUBNET-255.255.255.0

- **D2 Settings**

IP Configuration

Leave all the network settings as default

- **Your Computer's Settings**

Obtain IP Address Automatically

Obtain DNS Server Automatically

